

# Rim


NÁVOD K POUŽITÍ  
BEDIENUNGSANLEITUNG  
OPERATING INSTRUCTIONS  
MODE D'EMPLOI  
INSTRUKCJA UŻYTKOWANIA  
HASZNÁLATI ÚTMUTATÓ

**SPACE SP 1501**  
**SPACE SP 1502**




SYNCHRO STE


1



2




3

































Područky 093 3F  
Armlehnen 093 3F  
Armrests 093 3F  
Accoudoirs 093 3F  
Podłokietniki 093 3F  
Karfa 093 3F





SP 1502



4,1 cm

SP 1501  
SP 1502

Područky 094 4F  
Armlehnen 094 4F  
Armrests 094 4F  
Accoudoirs 094 4F  
Podłokietniki 094 4F  
Karfa 094 4F



# Rim

**RIM CZ a.s.**

Dr. E. Beneše 1015  
765 02 Otrokovice  
CZECH REPUBLIC

Tel.: +420 577 112 640  
E-mail: [info@rim.cz](mailto:info@rim.cz)

[www.rim.cz](http://www.rim.cz)

